STICK MIXER

Model RS2109SM

INSTRUCTION MANUAL

PLEASE SAVE THESE INSTRUCTIONS

Dear Valued Customer

Thank you for purchasing a Red Stamp appliance.

We understand the importance of your purchasing decision, and appreciate your final choice to introduce this Red Stamp product into your home.

Your Red Stamp appliance is recognised as a quality product at an affordable price, and is proudly supported by our after sales service team. We encourage you and your friends to choose from the range of Red Stamp appliances.

TECHNICAL INFORMATION

Please make sure that your house installation voltage corresponds to the voltage marked on the unit.

Mains supply: 230-240V ~ 50 Hz – AC only
Rated Power: 100Watts

SERVICE HELPLINE

In the unlikely event of failure or for product information please contact the below help lines during normal working hours.

New Zealand call 0800-898 580
Email: service@opnz.com

BEFORE FIRST USE

Your appliance has been packaged carefully to ensure the product reaches you in good condition. If the product has been damaged, dropped, has a malfunction in any way, or if the supply cord is damaged, immediately contact your retailer for replacement or repair.

Carefully unpack your appliance. Make sure you do not discard any packaging material until all parts of the appliance have been found.

Carefully wipe the exterior of the appliance to remove any dust that may have accumulated. Dry with a dry towel. Do not use harsh abrasive cleaners. Remove any label or sticker.
WARNING! Do not immerse appliance in water or any other liquids.

SAFETY AND ASEMBLY

Use and environment
Do not use outdoors. Do not leave in direct sunlight as this may damage the plastic. This appliance is for household use only, not commercial or industrial use. The power socket must be readily accessible so that the oven can be unplugged in an emergency.
This appliance must be connected to a suitable 230-240V ~ 50Hz power supply.
Assembly
The appliance can be split for easy cleaning. To assemble or disassemble, carefully turn the two halves in opposite directions.
Warning! Read all safety instructions before use.

OPERATION GUIDE

Avoid contact with moving parts. Keep hands, hair, clothing, as well as spatulas and other utensils away from blades during operation to reduce risk of injury to you and/or damage to the appliance.
This appliance can be used to chop small solid ingredients or to mix liquids. Cut larger ingredients into smaller pieces before placing into mixing bowl or container. If chopping fruits or vegetables, use a container with tall sides.
Do not place unnecessary strain on the motor by mixing mixtures that do not allow the blades to revolve freely.
Ensure the bowl of ingredients is secure. Place mixing blade into ingredients and turn on. Hold the stick mixer firmly. The mixer will turn off once power switch is released. This mixer has two power settings, LOW and HIGH.
During mixing, occasionally use a spatula (not supplied) to scrape mixture from the sides of the bowl to ensure that all the ingredients are thoroughly and evenly mixed.

Note: Short-term operation. This appliance is designed for short-term operation only and must not be continuously operated for periods of time in excess of 30 seconds. If operated continuously for up to 30 seconds, switch the appliance off for a period of 10 minutes and allow it to cool down completely before further operation.
Tips
Always dice solid foods first.
Do not use this appliance for meat preparation.
Not recommended for use with ice.
Warning!
Do not leave unattended while connected to the power supply and before assembling, disassembling and cleaning.
Do not let the supply cord hang over the edge of any bench or tabletop. There may be a risk of electric shock or physical harm should young children pull the appliance from the bench or tabletop.

MAINTENANCE AND CLEANING

Warning! Always disconnect the appliance from the power supply before assembling, disassembling and cleaning.

Allow your appliance to stop completely. WARNING! Never immerse your appliance motor assembly in water or other liquids.

Removing the front mixer assembly
Remove the forward mixing arm by twisting clockwise whilst holding the motor assembly arm firm. This will allow for easy cleaning of the blades. Wash in warm soapy water and dry with a dry towel completely before re-attachment.

Cleaning the rear motor assembly
Wipe the exterior of the rear motor assembly with a warm soft damp cloth. Dry with a dry towel.
Do not use harsh abrasives as they may damage any plastic, non-stick surface or the exterior finish.

Store your appliance in its original box or in a dry cupboard.

This appliance has been lubricated at production and requires no further lubrication. Do not attempt to service this appliance.

IMPORTANT SAFETY INSTRUCTIONS

When using electric appliances always observe safety regulations where applicable to reduce the risk of fire, electric shock and personal injury. Always check that the power supply corresponds to the voltage on the rating plate.

Supply
This appliance must be connected to a suitable 220-240V ~ 50Hz power supply. If using an extension cord, ensure that the extension cord is of a suitable 10amp power rating and of a suitable size. Fully uncoil any cord used as a coiled cord may overheat. It is not recommended to use other appliances on the same circuit as that supplying any critical appliance such as refrigerators, ovens or similar that may require constant electricity supply.

Supply cord and plug
Do not abuse or damage the power cord. Fully uncoil before use. If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.

Children
Caution. Keep out of reach of children. This appliance is not intended for use by young children or infirm persons. Young children must be supervised by a responsible person to ensure that they can operate the appliance safely. Young children should be supervised to ensure that they do not play with the appliance
WARNING: Only allow children to use the appliance without supervision when adequate instructions have been given so that the child is able to use the appliance in a safe way and understands the hazards of improper use.

IMPORTANT SAFETY INSTRUCTIONS (continued)

Use and environment

Do not use outdoors. Do not leave in direct sunlight as this may damage the plastic. This appliance is for household use only, not commercial or industrial use. The power socket must be readily accessible so that the oven can be unplugged in an emergency.

Damaged or dropped

Always inspect your appliance before use. Do not use this appliance if it has been damaged, dropped, left outdoors or dropped in water. Return it to an authorised service dealer for examination and repair.

Water

Do not immerse in water or other liquids or use near washbasins or sinks. Ensure that the appliance does not get wet (water splashes etc.) and do not use it with wet hands.

Danger to children

Safely dispose of plastic bags and other components of the packaging. They may be potentially dangerous to children.

ORIENTAL PACIFIC INTERNATIONAL LIMITED

Guarantee Card

This product is guaranteed against faulty materials and workmanship for a period of twelve months from the date of purchase. The obligation to the purchaser under this warranty is limited to servicing the unit and replacing defective parts when the product is returned freight prepaid to the retailer. This warranty becomes void if the product has been tampered with, damaged by accident, damaged in any other way by improper use or has been purchased second hand. All production orders have quality inspections. In the unlikely event of a deficiency, please contact the retailer from whom this product was purchased.

WARRANTY FOR APPLIANCES USED COMMERCIALLY LIMITED TO 90 DAYS

Type of Appliance: _____

Model No.: _____Purchase Date:_____

Product Purchased from_____

_____

Name:_____

Address:_____

_____ Phone Number: _____

IMPORTANT!

Please **retain this warranty card along with your purchase receipt.** Please do not post to the retailer or importer. If service is required, both of these documents are to be returned with the appliance to your retailer, otherwise a fee may be charged.